

- Double mechanical seal tandem arrangement
- Piping/instrument harness shall be supported from overhead structure or side stand such that no strain is put on tubing connected to seal gland.
- Containment seal chamber drain from non-condensing leakage on arrangement 2 seal.
- Leakage collection for zero to very low process emissions.
- Safety indicator for primary seal.

- May be used alone or with Plan 72 on containment seals.
- Fluids that condense at ambient temperature.
- High vapor pressure fluids, light hydrocarbons.
- Hazardous / toxic fluids.
- Clean, non-polymerizing, non-oxidizing fluids.